






# ASM OBDII TSI


Emissions Inspector Study Guide





Produced by the Texas Department of Public Safety


VIE-28 (5/05)


































### ACCELERATION SIMULATION MODE (ASM) TEST INSPECTOR'S GUIDE


**Texas Department of Public Safety** 

May 2005

Contains Copyrighted Material
Prepared by
dKC – de la Torre Klausmeier Consulting, Inc.

Under Contract with the Texas Department of Public Safety

©2005 TXDPS





Beginning in May 2002, most 1995 and older model vehicles in the Dallas and Houston Metropolitan areas will receive ASM (acceleration simulation mode) tests during their annual emissions and safety inspection.

The ASM test uses a dynamometer, or "rolling road," to simulate on-road driving conditions.

With the ASM test, HC, CO and oxides of nitrogen (NOx) emissions are measured during two modes: a high load / low speed (15 mph) condition (the 50/15 test) and a moderate load / moderate speed (25 mph) condition (the 25/25 test).

Only 1995 and older gasoline vehicles up to 25 years of age will be required to be ASM tested.

TXDPS Copyright 2002

Texas Department of Public Safety



ASM TESTING

### WHAT IS THE ASM TEST?

HC and NOx from motor vehicles are major constituents of Urban Smog.

The purpose of this course is to familiarize inspectors with the ASM test.

TXDPS Copyright 2002



#### WHY IS TEXAS SWITCHING TO THE ASM TEST?

Compared to the current Two-Speed Idle (TSI) test, the ASM test identifies a more emission-related problems and it is more difficult to get a vehicle to pass it without performing necessary repairs

With the TSI test emissions of NOx can not be evaluated, since a vehicle must be operated under load before NOx emissions can be accurately assessed.

The ASM test measures NOx along with HC and CO emissions. The inspection program is much more effective against smog when it measures NOx as well as HC.

TXDPS Copyright 2002

Texas Department of Public Safety



ASM TESTING

#### WHY IS TEXAS SWITCHING TO THE ASM TEST?

The TSI test does not identify as many HC and CO problems as the  $\operatorname{\mathsf{ASM}}$  test.

Many problems do not show-up during idle and high idle conditions.

With the TSI test, technicians can mask problems that are identified during idle and high idle tests with temporary measures.

For example, inducing a vacuum leak can mask a rich engine condition.

TXDPS Copyright 2002

Texas Department of Public Safety



ASM TESTING


#### **ASM Test System Components**

The primary new components of the ASM test system (termed ASM EIS) are the dynamometer and 5gas exhaust analyzer.

The dynamometer, or "rolling road" is used to simulate on-road driving conditions.

The 5-gas analyzer measures NOx as well as HC and CO emission levels.

Texas Department of Public Safety





**Rolls:** The dynamometer has two sets of rolls to support the vehicle's drive wheels.


You can test vehicles in either direction on the dynamometer.

**Dynamometer Lift System:** The ASM EIS uses a software-controlled lift system to allow vehicles to drive on and off the dynamometer.

Raising the lift, locks rolls in place, enabling the operator todrive the vehicle on and off the rolls.

Lowering the lift platform, unlocks the rolls, releasing them tospin freely during vehicle testing.

TXDPS Copyright 2002





#### VEHICLE RESTRAINTS

The ASM EIS includes three types of vehicle restraints: ratcheting tie-down straps, wheel chocks, and lateral wheel restraints.

All vehicles must be restrained in all directions (side-toside, as well as forward and backward).

Never operate an unrestrained vehicle on the dynamometer rolls! Vehicles normally move laterally (side-to-side) on the dynamometer. Front-wheel drive vehicles must be restrained from moving laterally on the dynamometer.

TXDPS Copyright 2002

Texas Department of Public Safety





ASM TESTING

### **Power Absorption Unit (PAU)**

The PAU has iron rotors and stationary field coils, which apply a vehicle-specific load to the dynamometer.

The PAU cover houses high-voltage components. Use extreme caution when removing it from the dynamometer.

Do NOT block the PAU cover vents with paper, cloth, boxes, etc.

Air must be able to pass through these openings. Be aware that the PAU cover becomes extremely hot during dynamometer operation. Use caution when near the PAU to avoid burns.

Texas Department of Public Safety





#### 5-Gas Emissions Analyzer

The 5-gas emissions analyzer measures Hydrocarbons (HC), Carbon Monoxide (CO), Nitric Oxide (NO), Carbon Dioxide (CO2), and Oxygen (O2).

The emissions analyzer uses different technologies to detect and measure exhaust pollutants:

Non-dispersive infrared technology measures HC, CO, and CO2. A NO cell measures nitric oxide. The NO cell must be replaced periodically.

An O2 cell measures oxygen. The O2 cell also requires periodic replacement.

TXDPS Copyright 2002

Texas Department of Public Safety



ASM TESTING

### **General Safety Tips**

The following safety tips must be followed to assure the safetyof the inspector:

If necessary, make repairs or replacements before you begin testing.

Inspect test vehicle for fluid leaks before driving it onto the dynamometer.

Make repairs before you begin testing.

NEVER make repairs to the vehicle's engine or engine compartment when the dynamometer is in use.

Texas Department of Public Safety



#### **General Safety Tips**

NEVER operate the dynamometer without first restraining the vehicle.

Connect all restraints, placing wheel chocks in front and behindthe non-drive wheels of the test vehicle.

Make sure the floor is clean and dry to keep the wheel chocks firmly in place.

NEVER operate the vehicle in reverse on the dynamometer, except when removing the vehicle.

Always raise the lift before exiting the vehicle from the dynamometer.

The vehicle operator MUST remain in the driver's seat at all times during a drive cycle test.

Do NOT attempt to get in or out of the vehicle while the dynamometer rolls are moving.

TXDPS Copyright 2002

Texas Department of Public Safety



ASM TESTING

#### General Safety Tips

NEVER operate the dynamometer without its cover panels in place. Using a dynamometer with exposed cavities and operating components can be extremely hazardous.

Clearly mark the test area and install protective guard railings, for your protection and that of your personnel.

NEVER allow personnel to stand on, or in contact with, the dynamometer when raising or lowering the lift.

The lift can produce more than 6,000 lbs. of lifting force and several places exist where hands and feet could be trapped and crushed.

TXDPS Copyright 2002

Texas Department of Public Safety



ASM TESTING

#### **General Safety Tips**

During dynamometer operation, personnel must maintain proper clearance.

Allow at least four feet of clearance to the front, rear and sides of the dynamometer.


Stay clear of the rolls, especially when the dynamometer is in se.

#### Beware of projectiles.

Tires rotating at high rates of speed can throw off stones and other embedded objects.

Wear approved safety glasses when in the vicinity of a vehicle under test.

Texas Department of Public Safety



A vehicle exiting the dynamometer in this manner may incur property damage and injury to personnel, snap the roll-to-roll drive coupling belt, and cause damage to internal dynamometer components.

ASM systems have augmented braking functions that reduce roll speed at appropriate times.

TXDPS Copyright 2002

Texas Department of Public Safety

ASM TESTING



With above ground installations, ALWAYS use extreme caution when driving on and off the ramps and platforms.

Always properly vent the exhaust gases during all emissions tests.

TXDPS Copyright 2002





Determine if the vehicle is front or rear wheel drive.

Drive onto dynamometer

Lower the lift

Stabilize and restrain vehicle on dynamometer

Precondition vehicle - 30 seconds

50/15 test - Maximum 90 Seconds, usually less than 30 seconds.

25/25 test - Maximum 90 Seconds, usually less than 30

A complete safety inspection will be performed on the vehicle prior to the ASM.

TXDPS Copyright 2002

Texas Department of Public Safety



ASM TESTING

#### Pre-Test Vehicle Inspection

To prevent vehicle damage, it is very important to conduct a thorough vehicle inspection before performing ASM testing. Problems withthe vehicle can permanently damage the vehicle or the ASM EIS.

Before testing, make certain that the vehicle can be safely tested on the dynamometer.

NEVER test Traction-Control or All-Wheel Drive vehicles on a single-axle, Two-Wheel Drive dynamometer.

Viscous couplings on many modern All-Wheel Drive systems tend to overheat, and may incur permanent damage as a result.

TXDPS Copyright 2002

Texas Department of Public Safety



ASM TESTING

### **Pre-Test Vehicle Inspection**

Confirm both drive wheel tires are the same size.

Adjust the tire pressure to the vehicle manufacturers specification (or as shown on the tire sidewall) and inspect the tread for defects, bulges, or tire cord protrusions.

Do *not* operate the vehicle on the dynamometer if a temporary spare tire ("space-saver") is installed on one of the vehicle's drive wheels (you shouldn't anyway), if tire cord is visible on any of the tires, or if there are any other tire defects.

Texas Department of Public Safety



#### **Pre-Test Vehicle Inspection**

Inspect the vehicle for fuel, coolant, and oil leaks.

Do *not* operate a vehicle on the dynamometer if it leaks fluid. Make sure vehicle fluid levels (oil, transmission, coolant, power steering, etc.) meet the vehicle manufacturer's requirements.

Inspect the vehicle for exhaust leaks. Repair any leaks before performing tests to prevent sample dilution errors and ensure accurate test results.

TXDPS Copyright 2002

Texas Department of Public Safety



ASM TESTING

#### **Enter Vehicle Parameters**

Vehicle parameters are used to determine the Equivalent Test Weight (ETW) and pass/fail standards.

ETW is used to set the dynamometer loadings.

Pass/fail standards depend on age, vehicle type, and ETW.

TXDPS Copyright 2002

Texas Department of Public Safety



ASM TESTING

#### Positioning Vehicle on the Dynamometer

Make certain the dynamometer lift plate is up. Raise the lift. Clear obstructions away from the driving path to the dynamometer.

Remove the lateral wheel restraints if they are attached to the dynamometer. Driving the vehicle onto the dynamometer when the restraints are in place can damage the vehicle and the lateal wheel restraints.

Position the vehicle's drive wheels in front of and square with the dynamometer rolls. If necessary, ask an assistant to direct you

Slowly drive the vehicle's drive wheels into position on the dynamometer rolls.

Lower the lift.

Align and restrain the vehicle on the dynamometer rolls.

Texas Department of Public Safety





Restraining the Vehicle

The analyzer will provide the following screen prompt:

IS THE VEHICLE A FRONT-WHEEL DRIVE? (YES/NO)

Front-wheel drive vehicle: Laterally stabilize, restrain and chock. Apply parking brake.

REAR -WHEEL DRIVE VEHICLE: RESTRAIN AND CHOCK.

TXDPS Copyright 2002

Texas Department of Public Safety




ASM TESTING


ALIGNING FRONT WHEEL DRIVE VEHICLES


Align the vehicle on the dynamometer rolls as follows:

- A. Apply the brakes.
- B. Shift the transmission to "Drive" for automatic transmissions or "First" for manual transmissions.
- C. Slowly release the brake or clutch so the tires rotate very slowly. Do not exceed 3 mph!
- D. Gently apply the brake once the vehicle settles and continue holding it.
- E. Shift the transmission to "Park" for automatic transmissions or "Neutral" for manual transmissions.

Texas Department of Public Safety







TXDPS Copyright 2002



The analyzer will prompt the technician to insert the sample probe into the tailpipe.

The technician will be prompted, as appropriate, on transmissiontype:

1. Automatic Transmissions

PLACE THE TRANSMISSION IN DRIVE. IF THE ENGINE RPM , PLACE THE TRANSMISSION IN **EXCEEDS** OVERDRIVE. (Value will be shown by test system)

2. Manual Transmissions

PLACE THE TRANSMISSION IN SECOND GEAR. KEEP ENGINE RPM BETWEEN \_\_\_\_ AND \_\_\_\_RPM. (Value will be shown by test system)

TXDPS Copyright 2002

Texas Department of Public Safety



ASM TESTING

#### Tire Drying

The analyzer will prompt the technician as follows:

DO THE TIRES NEED DRYING? (YES/NO)

If YES, the analyzer will require the technician to run the vehicle at any speed below 30 mph.

When the roll speed exceeds 1 mph, the screen will display the following delay message which will include the seconds that must be waited until the test mode can begin.

ONCE THE TIRES ARE DRY, YOU MUST WAIT AT IDLE FOR SECONDS PRIOR TO BEGINNING THE PRECONDITIONING MODE. (Value will be shown by test system)

TXDPS Copyright 2002

Texas Department of Public Safety



ASM TESTING

### **ASM-2 Pre Emissions Test Conditions**

The following conditions must be met before the ASM EIS begins the test sequence:

- a. Zero air, electronic span, ambient air, and hang up checks have been performed.
- b. The ASM EIS does not detect a "low-flow" or diluted exhaust condition.
- c. The engine idle speed is between 400 and 1250 RPM.
- d. The dynamometer rolls are not turning (speed <1 mph). If the roll speed exceeds this limit, or the engine speed exceeds 1250 RPM, the following delay message will be displayed:

DELAY TESTING, YOU MUST WAIT \_ SECONDS (Value will be shown by test system)

Texas Department of Public Safety



#### Preconditioning procedures

The analyzer will display the following prompt:

PRECONDITIONING CAN BEGIN. ACCELERATE GRADUALLY TO 15 MPH

The inspector must maintain this speed for 30 seconds.

If, at any time during the preconditioning mode, the speed and RPM criteria or the gear selection criteria fall outside the acceptable ranges, the software will display one of the following appropriate messages to prompt the driver to correct the problem.
OUTSIDE PRECONDITIONING SPEED LIMIT

LOW FLOW / OUTSIDE DILUTION SPECIFICATION OUTSIDE ENGINE RPM RANGE DYNO LOADING ERROR

TXDPS Copyright 2002

Texas Department of Public Safety



ASM TESTING

#### 50/15 TEST

At the conclusion of the preconditioning mode the analyzer will prompt the driver to maintain the vehicle at 15 mph  $\pm$  01 mph.

The system will display the 50/15 test speed with applicable speed limits, test time, and engine RPM.

The vehicle will pass the ASM 50/15 mode and the mode will be immediately terminated if the 10 second running average measured values for each pollutant are less than or equal to the applicable test standards.

If test criteria fall outside acceptable ranges, the analyzer will display messages to prompt the driver to correct the problem.

OUTSIDE TEST SPEED LIMIT OUTSIDE ENGINE RPM RANGE DYNO LOADING ERROR

LOW FLOW / OUTSIDE DILUTION SPECIFICATION

TXDPS Copyright 2002

Texas Department of Public Safety



ASM TESTING

#### 25/25 TEST

At the conclusion of the 50/15 test, the inspector will be prompted to increase speed to 25 mph.

The 25/25 mode will begin when the roll speed (and corresponding power) is stabilized at 25 mph  $\pm$  01 mph for five consecutive seconds.

A vehicle will pass the 25/25 test mode if the 10-second average readings for HC, CO and NO are all equal to or below the applicable standards for the vehicle.

If test criteria fall outside acceptable ranges, the software will display messages to prompt the driver to correct the problem.

OUTSIDE TEST SPEED LIMIT OUTSIDE ENGINE RPM RANGE DYNO LOADING ERROR

LOW FLOW / OUTSIDE DILUTION SPECIFICATION

Texas Department of Public Safety





If the test parameters fall out of pre-determined limits, the system will prompt the inspector to restart

TEST MODE MUST BE RESTARTED

Conditions Causing Test Mode Restart (either mode):

Acceleration violation

Dynamometer load outside of specification

Sample dilution

Analyzer "low flow" condition

Vehicle speed outside test limit

Engine speed outside of range

The maximum number of restarts is two, otherwise the test will  $\ensuremath{\text{le}}$  aborted.

TXDPS Copyright 2002

Texas Department of Public Safety



ASM TESTING

### **Second Chance Tests**

If all emissions results (HC, CO, and NO) for both ASM Modes are within 150% of the applicable standards, the system will give the following prompt:

SECOND CHANCE 50/15 TEST AUTHORIZED. PLEASE GRADUALLY DECELERATE TO 15 MPH AND REPEAT THE ASM 50/15 MODE.

If the vehicle fails the second-chance ASM50/15, then the vehicle will fail the test. Otherwise, the vehicle will also receive a second-chance ASM 25/25.

SECOND CHANCE 25/25 TEST AUTHORIZED. PLEASE CONTINUE SPEED AT 25 MPH.

If the vehicle passes the second chance 25/25 mode and passed the first chance ASM 50/15 mode, the vehicle will pass the ASM-2 test.

Texas Department of Public Safety



#### **GAS CAP TEST**

Every gasoline powered vehicle from 2-24 model years old will be checked to determine if the gas cap is missing or defective.  $\frac{1}{2} \left( \frac{1}{2} \right) = \frac{1}{2} \left( \frac{1}{2} \right) \left( \frac{1}{2$ 

- Conduct daily calibration check of gas cap testing device.
- Check for presence.
- Check for correct type of gas cap(s).
- Remove gas cap(s) and test using an approved testing device.
- Any gas cap(s) failing the initial test will be tested second time to verify failure.



TXDPS Copyright 2002

Texas Department of Public Safety



ASM TESTING

#### GAS CAP TEST

#### **EXEMPTIONS**

Slow-moving vehicles.

A motor vehicle designed to operate at a maximum speed of 25 miles per hour.

Motorcycles.

Vehicles operated exclusively by a fuel other than gasoline.

Vehicles newer than 2 years old and older than 24 years old.

TXDPS Copyright 2002

Texas Department of Public Safety




ASM TESTING


End of ASM-2 Emissions Test Mode


At the completion or termination of the ASM two-mode inspection, the analyzer will display the following message:


END OF ASM-2 EMISSIONS TEST
REMOVE RESTRAINING SYSTEM FROM VEHICLE.
REMOVE COOLING FAN, TACHOMETER LEAD AND
SAMPLE PROBE.


Texas Department of Public Safety











## On-Board Diagnostics II (OBD II) INSPECTOR'S GUIDE


Texas Department of Public Safety


May 2005


Contains Copyrighted Material
Prepared by
dKC – de la Torre Klausmeier Consulting, Inc.


Under Contract with the Texas Department of Public Safety


©2005 TXDPS




















The inspector must enter all required information as accurately and correctly as reasonably possible.


Incorrect information may cause inaccurate test results.


TXDPS Copyright 2002






























OBDII TESTING

#### Visual Inspection of the MIL

The inspector performs two checks of the

Key-On Engine Off (KOEO)


Key-On Engine Running (KOER)


WARNING: Failure to answer either question properly could result in a 6 month suspension of your inspector license.


TXDPS Copyright 2002

TXDPS Copyright 2002


Texas Department of Public Safety























DTCs have been recently cleared with a scan tool, all non-continuous components or systems will be set to


TXDPS Copyright 2002


"not ready".








































#### **CERTIFIED EMISSIONS INSPECTION STATIONS**

(TRAVIS AND WILLIAMSON COUNTIES ONLY)
Effective 9-1-2005

Certain vehicles experience significant difficulties undergoing the On-Board Diagnostic (OBDII) emissions test due to more than two monitors set to "Not Ready":

1996 & 1997 Milsubishi; 1996 & 1997 Hyundai; 1996, 1997 & 1998 Volvo; 1996 Subaru; 1996 Kia; and 1996 & 1997 Eagle

OBD/TSI Inspection Stations shall attempt testing using standard OBDII procedures. However, if the vehicle fails only for more than two monitors set to "Not Ready", then the vehicle will receive a Two-Speed side (151) failipipe fest. To minimize difficulties for both inspection stations and vehicle owners. The Department directs the following.

#### For vehicles listed above:

- OBD/TSL Inspection Stations will attempt the OBDII test. The vehicle will fail OBDII test if:
   MILL is commanded on and a Diagnostic Trouble Code (DTC) is stored in OBDII system, or
   Vehicle folls but bracks (CROCK, OCRR)
   If the above conditions are NOT present, but the vehicle has more than two monitors set to "Not Ready", then it must transition to the two-Speed feld [TSI] tablepa test.

#### For 1996 and newer vehicles that are not listed above:

OBD/TSI Inspection Stations – Vehicle will pass or fail based on standard OBDII testing procedure.

NOTE: If the DLC (Diagnostic Link Connector) is obstructed and/or tampering is readily apparent on 1996 and newer vehicles, it must fail - Do not use Two-Speed Idle (TSI) tailpipe test.



OBDII TESTING

## **GAS CAP TEST**

Every gasoline powered vehicle from 2-24 model years old will be checked to determine if the gas cap is missing or defective.

- Conduct daily calibration check of gas cap testing
- Check for presence.
- Check for correct type of gas cap(s).
- Remove gas cap(s) and test using an approved testing device.
- Any gas cap(s) failing the initial test will be tested second time to verify failure.



TXDPS Copyright 2002

Texas Department of Public Safety



OBDII TESTING

## **GAS CAP TEST**

#### **EXEMPTIONS**

Slow-moving vehicles.

A motor vehicle designed to operate at a maximum speed of 25 miles per hour.


Motorcycles.


Vehicles operated exclusively by a fuel other than gasoline.

Vehicles newer than 2 years old and older than 24 years old.

Texas Department of Public Safety

TXDPS Copyright 2002






# Two-Speed Idle (TSI) INSPECTOR'S GUIDE


Texas Department of Public Safety


May 2005


Prepared by Texas Department of Public Safety


©2005 TxDPS


















TSI TESTING

#### **TSI TEST PROCEDURES**

The inspector must enter all required information as accurately and correctly as reasonably possible. Incorrect information may cause inaccurate test results.

Pre-inspection - Is vehicle safe for testing?

Determine if the vehicle has a ZF-4 transmission. See Rules and Regulations Manual (Refer to the Emissions Manual reference section).

TXDPS Copyright 2005

Texas Department of Public Safety



# **NOTICE**



CERTIFIED EMISSIONS INSPECTION STATIONS (EL PASO, TRAVIS, AND WILLIAMSON COUNTIES ONLY) TSI TEST SEQUENCE - BMW/PEUGEOT/VOLVO/JAGUAR (ZF AUTOMATIC TRANSMISSIONS)

en the problems with the "ZF" automatic transmission, DPS prefers that the affected vehicles be tested at their dealerships. Accordingly, if the person or enters an "A" (for automatic) for the transmission type, and if the vehicle type and the vehicle make, model, and model year match BMW/PEU-CTACH MOULAGLIAB calcing.

BECAUSE OF THE POSSIBILITY OF TRANSMISSION DAMAGE TO THIS VEHICLE, DPS PREFERS THAT IT BE INSPECTED AT ITS DEALER-SHIP IF YOU STILL WISH TO PERFORM THE INSPECTION, YOU MAY DO SO AT YOUR OWN RISK, PRESS "ENTER" TO CONTINUE, IF NOT, PRESS "ESC" TO ABORT THE TEST, (ENTER ABORT CODE 6)

PRESS "ESC" TO ABORT THE TEST. (ENTER ABORT CODE 6)

If the inspector chooses to continue testing this yehicle, the following message will be displayed when beginning the test sequence:

BEFORE BEGINNING THE EMISSIONS TEST MAKE SURE THE BENGINE BY ARBING THE ROW WITH THE WINDLE THE TRANSMISSION IS IN PARK SHOULD BE DRIVEN UNTIL IT IS, DO NOT WARM THE ENGINE BY RAISING THE RPM ABOVE IDLE WHILE THE TRANSMISSION IS IN PARK OR INJETRAL.

OF NOTIFIED.

AFTER THE ENGINE REACHES NORMAL OPERATING TEMPERATURE DUT THE TRANSMISSION IN DADY AND TUDN THE ENGINE OFFICE

IO SECONDS. RESTART THE ENGINE. AFTER THE ENGINE IS RUNNING, <u>DO NOT</u> MOVE THE GEAR SHIFT SELECTOR THROUGH THE FOR-WARD OR REVERSE GEARS BEFORE OR DURING THE TEST SEQUENCE. <u>DO NOT EXCEED 2000 RPM.</u>

All 1984-87 BMWs with automatic transmissions, 1983-88 Volvo 740s with automatic transmissions, 1984-89 Jaguar XJSs, and 1986-92 Peugeot 505s with automatic transmissions shall be tested using this test sequence or the latest test sequence supplied by DPS.

CONTACT YOUR LOCAL DEPARTMENT OF PUBLIC SAFETY VEHICLE INSPECTION OFFICE IF YOU HAVE FURTHER QUESTIONS REGARDING ZF AUTOMATIC TRANSMISSIONS.

VIE-30 (5/04

